


Pos	SV	i	Ref.	Pos	SV	Type	i	Ref.
-----	----	---	------	-----	----	------	---	------

SCANIA

75 - 141		CL	F	451 722		216977			
		PL	F	500 109		216976			
	Ch. -489972								216975
	Ch. 489973-								258420 395064
82 92 112 142	4x2, 6x2	CL	F	451 722		216977 307111			
		PL	F	500 109		279011			
						1110588 216976			
	4x2								258420
	4x2 SPS 9*15 + 12*15	CL	R	500 039					216975
	6x2	PL	R	500 039				8	216975
	6x2	PL	R	500 124				9	328111
	4x2, 6x2 Ch. -1082195 (SSS), Ch. -4236835 (SN), -83/84	A	R	500 144				30	272400
		A	R	500 153				31	269692
		A	TAG	500 109					216976
	4x2, 6x2 Ch. 1082196- (SSS), Ch. 4236836- (SN), 83/84-	A	DA	500 144					272400
		A	TAG	500 144					272400
	6x4	A	R	500 039					279927
	6x2/4								1309129
		2FA	500 153					372291	
93 113 143		CL	F	451 722	I/O	279011 1340252			
		PL	F	500 109	I/O	1111056 1315959			
						1110588			
	MA Ch. 4316230 SNL ->	A	F	500 204	I/O	1327211			
	ML Ch. <-1179266 (SSS)	A	F	500 204	I/O	1122612 1354966			
	ML Ch. 1179267 -> (SSS)	A	F	450 038	I/O	1327145			
	MV, MW Ch. 1179586-1179585 (SSS)	A	F	500 155	I/O	1314479			
	MV, MW Ch. <- 4312231 (SNL)	A	F	500 155	I/O	1314479			
	MV, MW Ch. 1179586 -> (SSS)	A	F	450 038	I/O	1331756			
	MV, MW Ch. 4312232 -> (SNL)	A	F	450 038	I/O	1331756			
	4x2 SPS 7*15 + 6*14	CL	R	500 157	I/I				1340253 258420
	SPS 9*15 + 6*14, 12*15 + 6*14	CL	R	500 039	I/I				216975
	SPS 2*34 + 1*34	PL	R	500 157	I/I				1110589
	SPS 3*26 + 2*26	PL	R	500 157	I/I				258420 1340253
	Ch. -1159364 Holkki / Bush Ø16 Normal Duty HD	A	R	450 144	I/O				272400 1340254
				500 144					272400 1340254
	Ch. 1159365- Holkki / Bush Ø16 Normal Duty HD	A	R	450 144	I/O				1303235 1323476
				500 144					272400 1340254
	9 / 95 -->> Holkki / Bush Ø20	A	R	501 144	I/O				1377056
	MV, MW B Holkki / Bush Ø16	A	R	500 204	I/O				1334250 1314480
MV, MW B Ch. 1215500 (SSS) Holkki / Bush Ø20	A	R	502 204	I/O				1377058	
6x2	SPS 7*15 + 6*14	CL	R	500 157	I/I				1340253 258420
	SPS 9*15 + 6*14, 12*15 + 6*14	CL	R	500 039	I/I				216975
	HJB 28	CL	R	451 725	I/I				328111
	Ch. 1188656-> (SSS), 4320991-> (SNL)	CL	R	451 725	I/I				1340255
	HJB 28	PL	R	451 725	I/I				328111
	Ch. 1188656- (SSS), 4320991- (SNL), 9000095 -> (SAN)	PL	R	451 725	I/I				1315960
	Holkki / Bush Ø16 Normal Duty HD	A	R	450 144	I/O				1340254 272400
				500 144					1303235 1323476
	Holkki / Bush Ø16 Normal Duty HD	A	TAG	450 144	I/O				272400 1303235
				500 144					1340254 1323476
	9 / 95 -->> Holkki / Bush Ø20	A	R	501 144	I/O				1377056
	MV Holkki / Bush Ø16 F950	A	R	500 204	I/O				1334250 1314480
		A	TAG	500 204	I/O				1334250 1314480
	6x2/4	SPS 7x15 + 6x14	CL	R	500 157	I/I			
SPS 9x15 + 6x14, 12x15 + 6x14		CL	R	500 039	I/I				216975
SPS 2x34 + 1x34		PL	R	500 157	I/I				1110589
SPS 3x26 + 2x26		PL	R	500 157	I/I				258420 1340253
Holkki / Bush Ø16 Normal Duty HD		A	DA	450 144	I/O				1309129 1307332
		A	DA	500 144	I/O				1110531 1323476
									1340254 272400
9 / 95 -->> Holkki / Bush Ø20		A	R	501 144	I/O				1377056
Second steerable axle		A	STE	500 153	I/O	1110530 372291			
Toinen ohjaava akseli						1331755 1340257			1309128
SAF		A	TAG	500 176					2.376.0003.00
6x4		CL	R	500 039	I/I				279927
		CL	R	500 039	I/I				279927
	HL	PL	RR	450 038	I/O				1327813
	SPS 4x30	PL	RF	450 038	I/O				1327813
	HL	PL		500 155	I/O				1342787
	HL	PL		500 039	I/I				1342788
	Air susp. Ilma jousitus Holkki / Bush Ø16 Normal Duty HD	A	R	450 144	I/O				1303235 1323476
		A	R	500 144	I/O				1303235 1323476
	Air susp. 9 / 95 -->> Holkki / Bush Ø20	A	R	501 144	I/O				1377056
	ML 6x4 FB	A	R	500 039	I/I				1340256 279927



Pos	SV	i	Ref.	Pos	SV	Type	i	Ref.
-----	----	---	------	-----	----	------	---	------

SCANIA										
93 113 143	8x4	8x4				PL	R	450 038	I/O	1327813
		MK, HL 8x4	-->CH 1196488 (SSS), 4330222 (SN)				R	450 038	I/O	1327813
			-->CH 1196488 (SSS), 4330222 (SN)				RR	O	I/I	1327814
		MK 8x4, 4x30					R	500 155	I/O	1342787
							RR	500 039	I/I	1342788
		MK 8x4, 4x41					R	450 038	I/O	1327813
							RR	500 039	I/I	1353101
		HL					PL	R	450 038	I/O
					PL		500 155	I/O	1342787	
					PL		500 039	I/I	1342788	

94 114 124 144 164		CL	F	451 722	I/O	1381807						
		PL	F	451 722	I/O	1370267 1421062						
				HD 500109		1388417						
						1356723						
		C, G series low chassis	PL	F	450 110	I/O	1420474					
		Normal chassis - Norm. Runko	A	F	450 235	I/O	1371447					
		Heavy duty	A	F	500 235		1371448					
		Extra-low chassis - Erikois matala	A	F	502 204	I/O	1390898					
		AD 1300, AD 1500					Holkki / Bush Ø20x50	CL	R	501 144	I/O	1377057
		AD 1100P / 1500P					SPS12x20	CL	R	O	I/O	1384513
		AD 1300 P, AD 1500 P						CL		500 183	I/I	1381810
		AD 1300 BT 200 B / I					SPS 4 x 41	PL	RF	450 038	I/O	1327813
							SPS 4 x 30	PL	RF	500 155	I/O	1342787
							SPS 4x41, 4x30	PL	RR	500 039	I/I	1375832
		4 x 2 ADA 1300/1500P					SPS 3x26 + 2x26	PL		500 157	I/I	1397525 1381808
							Holkki / Bush Ø20x50	PL	R	502 204	I/O	1377058
							SPS 5 x 22	PL		500 183	I/I	1388416
		4 x 2 ADA 1300, ADA 1300 / 1500P ELC2					Holkki / Bush Ø20x50	A	R	501 719	O/O	1380425 1397523
		6 x 2, 6 x 4										
		4 x 2 ADA 1300, ADA 1300 / 1500P ELC2					Holkki / Bush Ø20x50	A	R	501 719	O/O	1380425 1397523
		6 x 2, 6 x 4										
		ADA 1300 ELC1						A	R	O	I/O	1371348
		6 x 4 ADA 1300x2					Holkki / Bush Ø20x50	A	RR	501 719	O/O	1380425 1397523
							Holkki / Bush Ø20x50	A	RF	502 205	O/O	1380424
	6 x 2 ASA 700, ASA 1000					Holkki / Bush Ø20x50	A	TAG	501 719	O/O	1380425	
	6 x 2 ASA 70, ASA 80					Holkki / Bush Ø16	A	TAG	450 144	I/O	1353105	
	Tukiakseli Middle axle						A		450 060	I/O	1401877 1454753	
R		CL	F	451 722	I/O	1421062						
		CL	F	O	I/O	1438542						
		PL	F	451 722	I/O	1370267 1421062						
		PL	F	450 110	I/O	1420474						
		Tractor extra low	A	F	502 204	I/O	1478501					
		Tractor low	A	F	O	I/O	1478540					
					450235							
		Tractor normal height	A	F	HD500235	I/O	1478499					
		Truck low	A	F	O	I/O	1478541					
					450235							
		Truck normal height	A	F	HD500235	I/O	1478500					
		Second front axle	A	F	502 204	I/O	1478501					
		4x2, 6x2					Check oe numbers, tarkista alkup. Numero !!	PL	R	500 157	I/I	1397525
		4x2, 6x2					Check oe numbers, tarkista alkup. Numero !!	PL	R	O	I/I	1404864
		4x2, 6x2					Check oe numbers, tarkista alkup. Numero !!	PL	R	500 183	I/I	1519629
		6x4, 8x4 Sps 4x41, 4x30					Check oe numbers, tarkista alkup. Numero !!	PL	R	450 119	O/O	1427423
		6x4 Sps 4x41, 4x30					Check oe numbers, tarkista alkup. Numero !!	PL	R	O	O/O	1427424
		AD1101P, BT300I					Check oe numbers, tarkista alkup. Numero !!	PL	R	O	O/O	1497641
		4x2E, 6x2/4L					Check oe numbers, tarkista alkup. Numero !!	A	RF	500 290	O/O	1478508 1519632
							Check oe numbers, tarkista alkup. Numero !!	A	R	502 205	O/O	1519630 1478506
							Check oe numbers, tarkista alkup. Numero !!	A	R	500 290	O/O	1519632
							Check oe numbers, tarkista alkup. Numero !!	A	R	501 719	O/O	1397523 1519631
							Check oe numbers, tarkista alkup. Numero !!	A	R	501 719	O/O	1478507
		Truck					Check oe numbers, tarkista alkup. Numero !!	A	R	O	O/O	1720603
	tractor					Check oe numbers, tarkista alkup. Numero !!	A	R	O	O/O	1492419 1720604	
	ASA 6x2, ARA6x2/4					Check oe numbers, tarkista alkup. Numero !!	A	TAG		O/O	1475806 1519630	
	ASA 6x2, ARA6x2/4					Check oe numbers, tarkista alkup. Numero !!	A	TAG	501 719	O/O	1397523 1478507	
	ARA 6x2/4 (middle axle)					Check oe numbers, tarkista alkup. Numero !!	A	TAG	450 060	I/O	1478511	